

## Easy to Install



**Step 1:** Remove the old showerhead by turning it counterclockwise (Fig. 1). Wipe off any debris from the threaded pipe. Wrap the supplied teflon tape clockwise around the threaded pipe (Fig. 2).



**Step 2:** Place the open portion of the cam-lock onto the shower pipe and rotate the cam-lock upward to the 12:00 o'clock position to lock (Fig. 3).



Secure the slide bar by pressing the suction cup firmly to the wall (Fig. 4). Suction cup works best on a clean tile surface.



**Step 3:** Install the diverter valve on the showerhead pipe. Turn clockwise with your hand to tighten.



**Note: Do not over-tighten.** (Fig. 5). Then, install the new wall-mount showerhead to the forward-facing diverter opening by turning it clockwise and tighten by hand. If additional tightening is required, place protective cloth on the swivel nut and tighten with a wrench (Fig. 6).



**Step 4:** Attach one end of the hose to the downward-facing diverter valve opening (Fig. 7).



Attach the other end of the hose to the hand-held showerhead (Fig. 8) and turn clockwise to tighten by hand.



**Step 5:** Rest the hand-held showerhead in the holder when not in use (Fig 9).



## Easy to Operate

Turn the 3-way diverter valve according to the desired use (Fig. 10): wall-mount showerhead alone (A), a combination of both showerheads (B), or hand-held showerhead alone (C).

