

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING

KEEP AWAY FROM WATER

DANGER - Any appliance is electrically live even when the switch is off. To reduce the risk of death by electric shock:

1. Always unplug appliance immediately after using.
2. Do not use while bathing or in the shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in, or drop into, water or other liquid.
5. If an appliance falls into water, unplug it immediately. Do not reach into the water.

WARNING - To reduce the risk of burns, electrocution, fire, or injury to persons:

1. This appliance should never be left unattended when plugged in.
2. Do not pull, twist, or wrap line cord around appliance.
3. This appliance should not be used by, on or near children or individuals with certain disabilities.

4. Use this appliance only for its intended use, as described in this manual. Do not use attachments not recommended by the manufacturer.

5. Never operate this appliance if it has a damaged cord or plug, if it is not working properly or if it has been dropped or damaged, or dropped into water. Return the appliance to the store or retailer where purchased or an authorized service center for examination and repair.

6. Keep the cord away from heated surfaces.

7. Never use while sleeping.

8. Never drop or insert any object into any opening.

9. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.

10. Unit is hot when in use. Do not let heated surfaces touch eyes or bare skin.

11. Do not place the heated unit directly on any surface while it is hot or plugged in.

12. Never block the air openings of the appliance or place on a soft surface such as a bed or couch, where the air openings may be blocked. Keep the air opening free of lint and other debris.

13. Do not use an extension cord with this appliance.

14. Do not touch hot surfaces of the appliance. Use handles or knobs.

15. Do not attempt to touch the housing of your appliance near the straightening plates, as it is hot when in use.

16. While emitting steam, this straightening iron may cause burns if it is used too close to the skin, scalp or eyes, or if it is used incorrectly.

17. To reduce the risk of contact with hot water emitting from steam vents, test straightening iron before each use by holding it away from body and operating steam function.

SAVE THESE INSTRUCTIONS OPERATING INSTRUCTIONS

This steam straightener is intended for household use. Use on Alternating Current (60 hertz) only. This unit is designed to be operated at 120 volts AC.

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

To turn on unit, plug into electrical outlet and switch on. The Power/Low default setting will become illuminated. To turn off, press On/Off button. Never leave your straightening iron unattended. However, should you fail to turn the unit off, it will automatically shut off within 60 minutes.

TO FILL WATER RESERVOIR

WARNING: Never remove when hot. Allow to cool before filling.

Remove reservoir from unit. Open rubber reservoir cap and fill with distilled water. Replace rubber cap and snap back onto unit.

2-STAGE STYLING AND ADVANCED TECHNOLOGY

You'll love what our new high-tech 2-stage styling system can do for your hair. As nano silver makes plates glide smoothly through hair, Tourmaline Ceramic™ smoothes hair's cuticle layer to protect it from heat damage.

The 2-step styling system first infuses hair with conditioning ionic steam, and then locks in all that healthy moisture with heated plates. The results are sensational: silky, shinier, pin-straight styles that last!

Keeping your straightener's easy-glide plates clean is effortless, because of its nonstick surface. Simply wipe plates with a damp cloth after each use to remove any product buildup.

The advanced Nano Silver Tourmaline Ceramic™ technology and our 2-stage styling system lets you achieve longer lasting salon-straight looks, every time you style!

You have the option to select low or high steam for perfectly smooth and straight results. For coarse hair, select the high steam setting.

RETRACTABLE DETANGLING COMBS

The retractable detangling combs separate tangles and tame even the most unruly frizz!

Three different comb heights, high, low and off, make this the perfect straightener for any hair type, even thick and coarse textures.

The three settings let you choose from low to maximum tension control. Set the comb height that is best for your hair type.

Nano Silver Tourmaline Ceramic™ coating on the combs provides smooth glide and shiny, healthy looking results.

TO STRAIGHTEN AND STYLE HAIR

Hair should be clean and dry before using this appliance. For best results, use a light styling product prior to blow-drying.

To get started, pick up a section of hair that is 1½" wide and not more than ½" thick. Make sure it is free of tangles. Place the hair section between the two hot plates, close to the scalp, trapping the hair by firmly squeezing the handles together.

Maintaining a firm grip, slowly slide the iron down hair section toward the end. When you reach the end of the hair section, release your grip on the handles and allow the hair to gently slide out.

WARNING: While using steam feature, do not place fingers on the ridged area of the reservoir.

IONIC BENEFITS

Ionic properties neutralize positive charges in the air, reducing the static electricity that dulls hair and causes fly-away frizzies. Hair instantly becomes more manageable and shiny.

TIPS FOR USING THE HEAT SETTINGS

If your hair is delicate, thin and easy to straighten, minimum heat will be needed. Set the temperature control to a low 285° F.

Average to thick, or chemically treated hair will straighten best at a medium heat of 310° F.

Thick hair benefits from medium to high heat at 330° F.

Coarse, hard-to-straighten hair requires high to maximum heat at 360° F to 395° F.

The uniform heat recovery system maintains the plates at a constant temperature, for consistent results.

Experience is the best teacher – after using the iron several times, you will know the best way to straighten and style your hair.

GET TO KNOW YOUR HIGH TEMPERATURE STEAM STRAIGHTENER

3 position off/low/high detangling combs gently separate hair and create tension for smoother, straighter results

Nano Silver, Ionic, and Tourmaline Ceramic™ Technologies eliminate frizz and helps protect hair from damage



Ionic steam mist conditions hair and seals in moisture for maximum shine and a healthy look.


2-Stage Styling System

- Ionic steam mist moisturizes hair
- Heated plates lock it in for longer lasting results.


2 In 1 Heat-Resistant Storage Pouch and Counter Mat



Fold and snap closed to store hot styling iron safely.



Open mat to protect counters from heat while styling.



Divider separates power cord to safely store hot iron.

USER MAINTENANCE

Your High Temperature Steam Straightener is virtually maintenance free. No lubrication is needed. Keep all vents and openings clear of dirt and dust. If cleaning becomes necessary, disconnect the unit from the power source, allow to cool and wipe exterior with a cloth. If any abnormal condition occurs, unplug the unit, allow it to cool, and return it for repair to an authorized service representative only. No repairs should be attempted by the consumer.

CAUTION


NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the appliance. Damage will occur at the high flex point of entry into the appliance, causing it to rupture and short circuit. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.

STORAGE

When not in use, your appliance is easy to store. Allow appliance to cool, then simply store out of reach of children in a safe, dry location. **Do not jerk or strain cord at plug connections.** Do not wrap the line cord around the appliance. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.

**WARNING:
IF YOU THINK THE
POWER IS OFF WHEN
THE SWITCH IS OFF
YOU'RE WRONG.**

KEEP AWAY FROM WATER



Everyone knows that electricity and water are a dangerous combination. But did you know that an electric appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

ALWAYS UNPLUG SMALL APPLIANCES

LIMITED FIVE-YEAR WARRANTY

Conair will repair or replace (at our option) your unit free of charge for 60 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed below, together with your purchase receipt and \$5.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 60 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 60-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.



Service Center

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.
Glendale, AZ 85307

For information on any Conair or Infiniti by Conair product call 1-800-3-CONAIR or visit us on the web at: www.conair.com/infiniti

©2008 Conair Corporation
150 Milford Road, East Windsor, NJ 08520
7475 N. Glen Harbor Blvd., Glendale, AZ 85307

Patent Pending

07NP153

IB-7923

High Temperature Steam Straightener



Instruction & Styling Guide

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.



Model SS9